


Nevada Dealer: Quick Guide

The goal of the Nevada Dealer is to provide reliable dispensing and accounting of Nevada Ticket sales. The Nevada Dealer ticket dispenser is crafted using high quality materials and will provide for years of trouble-free use with virtually no maintenance. To ensure consistent operation, please adhere to the following guidelines:

OPERATION

Loading Tickets

- When loading tickets into an empty column, place push-rod levers into a mid-stroke position. Load columns as desired. Push all levers completely forward. You're ready to begin vending.
- Tickets usually tend to curve in either one direction or the other. When loading tickets, the curved edges must be facing down or the push-rod levers will slide under the ticket and the tickets will not eject. *See the figure at right for correct loading of the tickets ▶*



Dispensing Tickets

- When dispensing tickets a **full stroke** of the push-rod lever must be made. Push the lever to the maximum distance in both the forward and reverse direction. Should a partial forward stroke be made the ticket will not fall into the catch tray and it will be necessary to manually remove it. This security feature ensures that tickets are not counted twice.
- The levers are to be left in the forward position (Park Position) after the tickets are vended. This is important to the operation as the backward motion loads the bottom ticket and preps it for proper dispensing.

MAINTENANCE

- The push levers are made from a durable and self-lubricating plastic. Please **DO NOT** apply any type of lubricant to these levers. This may cause paper ticket fibers to build up and jam the levers.
- The casing of the dispenser can be cleaned using a clean damp cloth. No abrasive cleaners should be used as they will scratch the surface.
- The only periodic maintenance that may be required is to remove ticket dust build-up from the ticket bed. This can be done by vacuuming or blowing the dust out with compressed air, such as those used for cleaning out computer keyboards. Cans of compressed air can be obtained at retail computer outlets or hardware stores.

TROUBLE SHOOTING

- A ticket may jam in a column if not loaded properly. Remove the tickets and ensure that they are loaded curve side down.
- A ticket jam may occur if the column gate is not calibrated properly. Please contact your Sales Representative to recalibrate.
- If moving the dispenser please lift it from the bottom particularly if the ticket load door is not secured in place. Lifting the dispenser by grabbing underneath the top panel with the load door removed will put stress on the seams and may cause a crack in the housing.

Should you have any other questions or issues, please contact your Nevada Sales Representative:

Name: _____

Phone: _____